




# A560 Hopper Refill Procedure




- 1) Open Main Door and Refill Page will appear.  
Press **REFILL HOPPER**:



- 2) Press **YES** to confirm Refill:



- 3) A Hopper Refill Confirmation Page will appear.  
This will show the current Refill Soft meter:



- 4) Close Main Door
- 5) Press **Back**
- 6) Press **Back**
- 7) Press **EXIT**
- 8) Use **Reset Key** to Clear Hopper Empty Error Message
- 9) Press **Collect** and remaining coins will pay out.

To force a manual hopper refill, **open main door**, go to **Audit Mode** by turning reset key backwards, select **Maintenance**, then select **Hopper Refill** and follow instructions above.

# A560 Cancel Credit Procedure

- 1) If the collect button is pushed when the credit meter is more than \$200.00 or less than \$2.00 then the machine will lock up with a Cancel Credit Error message.



- 2) Before performing the cancel credit, record the cancel credit details on the venue's Cancel Credit, Short Pay and Refill Register

- 3) Turn the Reset Key towards you to Key Off the Cancel Credit.

- 4) Turn the reset key away from you to bring up the Audit Mode, select **Meters** (using touch screen)



- 5) Record the Cancel Credit Soft Meter Value from the Meters Screen



- 6) Press **BACK** and then **EXIT** to return to game screen